


MShare E2 Installation


Package Contents



NOTE

We recommend that you use the accessories provided or approved by Yealink. The use of unapproved third-party accessories may result in poor performance.

Connection



NOTE

The maximum length requirements for the cable are as follows:


USB A-B: 7m

USB C-C: 2m


HDMI: 8m

Installation


1. Stick the velcros on the back of MShare E2



2. Put the MShare E2 on a surface such as a table, wall, and so on.



3. Attach the cable tie mounting base onto a surface. Fix the cables with the cable tie.



LED Indicator Instructions

LED Status	Description
------------	-------------

Solid Yellow	MShare E2 is connected to a PC for content sharing via HDMI/USB-C.
Solid Green	MShare E2 is connected to a PC for content sharing via HDMI/USB-C.
Solid Red	MShare E2 is in sleep mode.
Fast-flashing Yellow	MShare E2 is upgrading firmware.
Slow-flashing Red	Failed to upgrade firmware.

Hardware Interface

Please refer to [MVC Hardware Overview - MShare E2](#) for details.