



# INSTALLATION MANUAL




Product nr: WC4300-0101  
WC4900-0101  
WC5500-0101  
WC6500-0101  
WC7500-0101


## List of parts



# ASSEMBLY INSTRUCTIONS



**Step 1**  
Mark drill holes




**Step 2**  
Drill holes (4x)




### Step 3

Mount a A1 bracket to the wall





### Step 4

Mount a B1 bracket to A1 on the wall




Do not forget to attach the adjusting screw!





## Step 5

Attach D1 (4x) screw to display (backside)



## Step 6

Hook display onto wall B1 brackets



## Step 7

Attach C1 bracket to E1



## Step 8

Attach E1 bracket to A1

